BARSKA® Boresighter Instructions



Warning: Be certain that the gun is not loaded, the action is open, and the muzzle is pointed in a safe direction. Safe gun handling procedures must be used at all times

1. Insert the Stud to Firearm Muzzle

Insert smaller end of the boresighter into the muzzle of the firearm. If stud does not fit snugly, remove stud and turn the screw clockwise or counter clockwise with screwdriver this will either increase or decrease the width of the stud. Place into muzzle.

2. Attach the Laser Sight

Once stud is in the muzzle, screw in laser sight into other end of stud. Laser sight is already pre zeroed. Align cross hairs with red laser dot.

Warning: Eye and ear protection is strongly recommended. Safe gun handling procedures must be used at all times.

The Barska Airgun Laser Boresighter is designed to save you time and money by allowing you to pre-zero the scope. Final steps in zeroing should be done at the range.

Parts Included in Package	Units
Laser Sight	1
Arbor Stud	1
Screwdriver	1
Allen Wrench	1
Batteries	3

BC135